FINGERPRINT BAG LOCK











I .USB Interface:

The product is charged by USB. Please fully charge the product for the first time



Components:

.USB Port

2.Fingerprint Reader

3.LED Light 4.Wire Rope


II .Indicator

Use 3-color indicator. Different indicator represents different devices and status.

Please check the details as below chart:

Indicator status	Function
Low power	Red light flash
Charging	Red light always on
Full charged	Lights off
Green light flash	Fingerpant collection mode
Green light always on	Successful to collect fingerprint
Blue light always on	Administrator fingerprint authorization
Green light flashes fast	Unlocked successfully
Red light always on	Delete fingerprint mode
Red light flash	Failed to collect fingerpnn

III . Description Of First Administrator's Fingerprint Record




- 5.It records successfu when blue light flash Remarks:

 1. Please confirm that the fingerprint lock is locked before recording the fingerprint,

 2. Please pull out the lock rope manually after the fingerprint is unlocked successfully

 3. Please insert and press the lock rope when intend to lock.

IV. Number 2 to 10 Fingerprint Recording Instructions



1.Long press sensor 3 seconds

continuously

4. Record 10 times with the same finger, and the blue light and green light flashes

6.Total of 10 times of collection was successful, with a loud sound "di" ,and green light flash continuously, the fingerprint was recorded successfully 5.lt records successful when blue light flash

- when the confirm that the fingerprint lock is locked before recording the fingerprint.

 The first and second fingerprints are the administrator fingerprint by default.

 Collecting the second to tenth fingerprints requires administrator fingerprint authorization.



1.Long pr sensor 1(seconds

2.Administrator authonze fingerprint when red light flash continuously



3. The fingerprint was deleted successfully when green light flash continuously and sound

VI.Specifications

Support 360 degree angel fingerprint recognize Resolution: 508DPI ESD: +/- 12kV air. ÷/-8kV contact FRR: <1% FAR: <0.002% PAR: <0.002% Recognize time: <300mS Battery: 3.7V 240mAh(Unlock:1000 times) Standby time: 1 Year Charger, 5V 1A

- Please confirm that the fingerprint lock is locked before delete the fingerprint.
 Only the administrator can delete the fingerprint and delete all the fingerprints at once.
- VII.Low voltage