

Portable Rechargeable Work Light **User manual for RNO-107**







Dimmer control for both lights (Adjustable individually)



Dust & water resistant

Tough construction

Box Content:

Steel **Hanging Hook**

- » 1x RNO-107 work light
- » 1x micro-USB cable
- » User manual

Charging Instruction

- 1. The RNO-107 comes 80-90% charged and can be used straight away. However, we recommend that you fully charged the unit before using it for the first time.
- 2. Charge the unit before the battery runs flat. This will help extend the life of the rechargeable battery.
- 3. Open the rubber seal and insert the USB cable (included in the box) into the charging port as shown below. Turn on the power.



- 4. Once the unit is fully charged, disconnect the unit from the power source. Remember to close the rubber seal.
- 5. Do not attempt to open the battery compartment unless you are replacing the battery.
- 6. Keep the battery away from extreme temperature or heat source and naked flame

Replacing the battery

1. Un-tighten the screw at the base of the unit with a cross screwdriver. Slide open the battery cover.

with a new Type 18650

3.7v 2000mAh battery.





3. Slide the battery cover back on and re-tighten the screw.

WARNINGS

- 1. The unit is extremely bright and the lighting surface can be very hot after using for a duration. Hence, avoid looking directly into the lights or touch the main light panel when when the light is being used.
- 2. Please keep the unit away from children.

Technical Specifications

Material	PC + TPR + Aluminum
Product Size	Folded: 150 x 30 x 35 mm Unfolded: 270 x 30 x 35 mm
Product Weight	162g (including battery)
Battery Type	3.7v, 2000mAh Li-ion 18650 battery
Charging Time	About 2 hours
Input Voltage & Current	5V, 1A
Protection Rating	IP62
Lighting Type	Dome light: 3W LED (140 Lumen) Main light: 5W COB LED (360 Lumen)
Working Time (at max. intensity)	Dome light: ~4 hours Main light: ~3 hours

Warranty information

Our company provides a 90 (ninety) day limited warranty guarantee. If you have any problem during this time, please contact us. This warranty does not apply

- (a) to consumable parts, such as batteries or protective coatings that are designed to diminish over time unless failure has occurred due to a defect in materials or workmanship.
- (b) to cosmetic damage, including but not limited to scratches, dents and broken plastic on ports unless failure has occurred due to defect in materials or workmanship.
- (c) to damage caused by use with a third party component or product outside of package contents.
- (d) to damage caused by accident, abuse, misuse, fire, liquid contact, earthquake or other external cause.
- (e) to damage caused by operating the product outside the manufacturer's published guidelines.
- (f) to damage caused by service performed by anyone who is not a representative of the manufacturer.
- (g) to a product that has been modified to alter functionality or capability without the written permission of the manufacturer.
- (h) to defects caused by normal wear and tear or otherwise due to the normal ageing of the product.
- (i) if any serial number has been removed or defaced from the product.

Please visit www.alpskgizmo.com to register your product within 14 days of purhcase to be eligible for the warranty.