



Bright. Dependable. Versatile

Portable Rechargeable Work Light

USER MANUAL FOR RNO-170



Part Description



Anti-slip



Dust & water resistant



Tough



Rechargeable 3.7v 4000mAh battery



Battery level

Charging dock

Box content:

- » 1x RNO-170 work light
- » 1x USB-C charging cable
- » 1x charging dock
- » User manual



Dimmer control:

Press & hold (+) button to increase brightness & (-) button to dim.

The brightness level is retained until the next setting.

4 types of light:

- Press (cycle option)
- > Dome flashlight
- > Main floodlight (White)
- > Main floodlight (Red)
- > Main floodlight (Blinking Red)

USB-C Charging Cable

Heat sink

Charging & Output USB ports

Hanging hook

Belt clip with magnet

Magnetic base

Swivel Ball Hinge
360° rotation + tilt angle

Charging Instruction

1. The RNO-170 comes 80-90% charged and can be used straight away. However, we recommend that you fully charge the unit before using it for the first time.
2. Charge the light before the battery runs flat. This will help extend the life of the rechargeable battery.

Using the charging dock

3. Connect the USB-C cable (included in the box) into the charging dock. Turn on the power.

4. Place the RNO-170 onto the dock. Once the light is fully charged, remove the unit from the dock. Turn off the power.

Using the charging cable

3. Open the rubber seal and insert the USB-C cable (included in the box) into the charging port. Turn on the power.

4. Once the light is fully charged, disconnect the unit from the power source. Remember to close the rubber seal.

5. Do not attempt to open the light to replace the battery. Keep the light away from extreme temperature or heat source and naked flame.



LED (Battery) status:

Charging: Blinks GREEN

Fully Charged: Solid GREEN

Each LED bar indicates ~20% power

Charging Other Devices

1. The RNO-170 can be used as an emergency power bank for your smartphone or other small device via the USB output port (not the USB-C input port).
2. Open the rubber seal and connect your device charging cable to the USB port. Turn on the light.
3. Once your device is charged, disconnect the charging cable from the USB port. Remember to close the rubber seal.

Charge your smartphone or other device using the USB output port (not the USB-C input port)

Charge the RNO-170 using the USB-C input port



Warning

1. The light is extremely bright and the lighting surface can be very hot after using for a duration. Hence, avoid looking directly into the lights or touch the main light panel when using the light.
2. Please keep the light away from children

Technical Specifications

Material	PC + TPR + ABS + Aluminum
Product Size	Light: 198 x 63 x 29 mm Charging dock: 112 x 78 x 81 mm
Product Weight	355g
Battery Type	3.7v, 4000mAh Li-ion Rechargeable battery
Charging Time	About 5 hours
Voltage & Current	Input: 5V, 1A Output: 5V, 1A
Protection Rating	IP54
Lighting Type	Dome flashlight: 5W LED (250 Lumen) Main light: 10W COB LED (550 Lumen)
Working Time	Dome flashlight: 5-6 hours Main light: 5-6 hours

Warranty Information

Our company provides a 90 (ninety) day limited warranty guarantee.

If you have any problem during this time, please contact us.

This warranty does not apply

- (a) to consumable parts, such as batteries or protective coatings that are designed to diminish over time unless failure has occurred due to a defect in materials or workmanship.
- (b) to cosmetic damage, including but not limited to scratches, dents and broken plastic on ports unless failure has occurred due to defect in materials or workmanship.
- (c) to damaged caused by use with a third party component or product outside of package contents.
- (d) to damage caused by accident, abuse, misuse, fire, liquid contact, earthquake, or other external cause.
- (e) to damage caused by operating the product outside the manufacturer's published guidelines.
- (f) to damage caused by service performed by anyone who is not a representative of the manufacturer.
- (g) to a product that has been modified to alter functionality or capability without the written permission of the manufacturer.
- (h) to defects caused by normal wear and tear or otherwise due to the normal aging of the product.

(i) if any serial number has been removed or defaced from the product.

Please visit www.alpskgizmo.com to register your product within 14 days of purchase to be eligible for the warranty.