

3. User manual

1. Connect the USB cable to the power adaptor. 2. Plug the power adaptor into the wall socket. 3. The LED indicator turns Blue to indicate that the charger is in standby mode. 4. Place the Qi compatible smartphone onto the charger. When the phone is placed correctly, the LED indicator will turn from Blue to Green. This indicates that charging is in progress. 5. When the phone is removed from the charger, the LED indicator will turn to Blue and enters into standby mode. **21** 🖟 USB Cable Important Note: The charger only supports fast charging when used with QC2.0/QC3.0 Standard power adapter. The adapter is not included and is to be bought separately.

Installation

1. Blue LED light: Charger is in standby mode. 2. Green LED light: Charger is charging normally. 3. Blue LED light flashing: Error detected. There are 3 possible causes

LED Light Status Indicator

» The smartphone is not properly placed on the charger.

Action: Place the smartphone squarely on the charger. » The charger is in overheat protection mode (exceeds 60°C)

Action: Remove the smartphone and turn off the charger to allow it to cool down before using again. » The charger detects a ferromagnetic/conductive metal object in close

vicinity of the charging pad. Action: Move any metallic object at least 20 cm away from the charging pad

Warnings

1. For the best charging efficiency, remove the protective case of the smartphone during charging and use a 2A power adaptor.

may damage the unit.

medical device

6. Keep the charger away from children for safety reasons

The may cause the charger to short-circuit.

4. Do not use the charger in a hot, humid or corrosive environment. This

Keep any wearable medical device like pacemaker & hearing aid at least

20 cm away from the charger to avoid potential interference with the

2. Do not disassemble the charger.

3. Do not spill water on the charger or put the charger near a heat source.

(h) to defects caused by normal wear and tear or otherwise due to the normal

(i) if any serial number has been removed or defaced from the product.

written permission of the manufacturer.

purhcase to be eligible for the warranty.

Warranty information

workmanship.

workmanship

package contents.

or other external cause.

published guidelines.

of the manufacturer

ageing of the product.

Please visit www.alpskgizmo.com to register your product within 14 days of

Our company provides a 90 (ninety) day limited warranty guarantee. If you have

(a) to consumable parts, such as batteries or protective coatings that are designed

(b) to cosmetic damage, including but not limited to scratches, dents and broken

plastic on ports unless failure has occurred due to defect in materials or

(c) to damage caused by use with a third party component or product outside of

(d) to damage caused by accident, abuse, misuse, fire, liquid contact, earthquake

(f) to damage caused by service performed by anyone who is not a representative

(g) to a Product that has been modified to alter functionality or capability without the

(e) to damage caused by operating the product outside the manufacturer's

to diminish over time unless failure has occurred due to a defect in materials or

any problem during this time, please contact us. This warranty does not apply